>
>
> TO MAKE COPY OF VIPERSOFT - WITH "AUTO WRITE" OFF & VIPERSOFT UP & RUNNING
>
>_> USE "PUT %(24576), 4096"
>
>
>
>TO LOAD VIPER SOFT LANGUAGE....
>
>USING THE AB CARTRIDGE AND BALLY KEYBOARD TPYE IN THE FOLLOWING..
>
>   &(192)=0%:INPUT %(24576)
>AND RUN THE TAPE. WHEN THE CURSOR RE-APPEARS TYPE IN [illegible]576"
>"VIPERSOFT" [illegible] ON THE SCREEN IN SMALL LETT[illegible]
>
>INPUTTING TO MEMORY USE "LOAD". GOING TO THE TAPE RECORDER USE "SAVE".
>
>: